



CW-010 / STACKING TUMBLER SILVER
CW-011 / STACKING TUMBLER BLACK

MANUAL - Ver 1.00

EN

■ HANDLING PRECAUTIONS

Please follow these guidelines to avoid property damage and to ensure the safety of yourself and others.



**INDICATES SITUATIONS THAT COULD
RESULT IN SERIOUS INJURY OR DEATH.**

WARNING

- Keep out of reach of infants and children to avoid burns and injuries.
- Do not boil or use over direct heat. Doing so may cause the product to rupture.
- Keep away from open flames as this may cause rupture, warping, discoloration, or burns.
- Never use with microwave ovens, gas stoves, IH stoves, or ovens. Doing so may cause rupture, damage, malfunction, or burns.



**INDICATES SITUATIONS THAT COULD CAUSE
MINOR INJURY OR PROPERTY DAMAGE.**

CAUTION

- Wash thoroughly before using. Check product after each use. Immediately discontinue use if any abnormality is found.
- Do not leave drinks or other liquids in this product for extended periods of time as this may cause the contents to change in quality and spoil.
- Avoid any strong impact. Dropping, bumping, and hitting the vessel may cause damage or affect its insulating properties.
- Do not forcefully stack or twist tumblers together, as this may scratch and damage the product.
- Up to six tumblers can be stacked at one time. Stacking more than this could cause them to tip over and be scratched or damaged.
- Do not remove the sticker attached to the bottom as this may cause rust or damage.
- Do not modify, as this may impair performance.

- To clean, wash with dish soap and a soft sponge. After rinsing, dry thoroughly before storing.
- Do not soak in water for extended periods of time as this may cause rust or damage.
- Do not use thinners, benzine, scouring powder, bleach, or metal scrubbers on this product. Doing so may cause rust, scratches, discoloration, and the coating and sticker to peel.
- Do not clean in dishwashers or dryers. This may deform, damage, or cause the coating and sticker to peel.

■ WARRANTY AND REPAIR

If you find any defects in the product, please contact the store where you purchased it or us directly. We will replace or repair any item found to have a manufacturing defect free of charge. We will repair products with damage caused by wear and aging at a reasonable price. Please note that it may be difficult to obtain some materials due to the discontinuation of products and parts, and repairs may not be possible based on the condition of the product.

※ When sending a product for repair, please remove dirt and moisture from the product before sending it. Moisture and dirt may interfere with repairs. Items that are not clean and dry upon arrival for repair will incur additional charges at their own expense for cleaning. Thank you for your understanding.

ZANE ARTS, Inc.

7190-2 Shimauchi, Matsumoto, Nagano 390-0851

Phone: 0263-87-2955 FAX: 0263-87-2966

info@zanearts.com